



3952 West 12th Street, Erie, PA, 16505 Phone: (814) 836-5782 Fax: (814) 835-7072

Oil Filter Mounting Bracket Installation Instructions 1999 to 2007 Twin Cam A Motors

Part No. HPI-OC-1

Installation Instructions:

- Basic Hand Tools are required for removal/installation of HPI Oil Filter Bracket. Draining Oil is not necessary, but may be done so if desired.
- Start by locating stock mounting bracket, bolts, and retainer. Bend back retaining ring and remove 3 retaining bolts and retainer ring. Remove stock filter mount and stock gasket or o-ring and discard. Oil feed and return lines may be mounted in either both vertical or both horizontal position to accommodate any style of cooler. Plug off the other holes with supplied npt plugs. Use of thread sealant or tape as advised. Position supplied o-rings on HPI bracket and align on motorcycle. Place a small dab of Blue loctite 242 on each bolt and thread in until seated, making sure the o-rings have not moved out of position. Finish tightening bolts to 120 in. lbs. Hook cooler lines to new HPI feed/return lines and install clamps.
- Start engine and check for oil leaks.
- Check oil level
- Ride and enjoy a new level of Cool!



3952 West 12th Street, Erie, PA, 16505 Phone: (814) 836-5782 Fax: (814) 835-7072

Oil Filter Mounting Bracket Installation Instructions 1999 to 2007 Twin Cam A Motors

Part No. HPI-OC-1

Installation Instructions:

- Basic Hand Tools are required for removal/installation of HPI Oil Filter Bracket. Draining Oil is not necessary, but may be done so if desired.
- Start by locating stock mounting bracket, bolts, and retainer. Bend back retaining ring and remove 3 retaining bolts and retainer ring. Remove stock filter mount and stock gasket or o-ring and discard. Oil feed and return lines may be mounted in either both vertical or both horizontal position to accommodate any style of cooler. Plug off the other holes with supplied npt plugs. Use of thread sealant or tape as advised. Position supplied o-rings on HPI bracket and align on motorcycle. Place a small dab of Blue loctite 242 on each bolt and thread in until seated, making sure the o-rings have not moved out of position. Finish tightening bolts to 120 in. lbs. Hook cooler lines to new HPI feed/return lines and install clamps.
- Start engine and check for oil leaks.
- Check oil level
- Ride and enjoy a new level of Cool!